




220-ohm resistors (fixes glitching)

220-uF capacitors (optional, does not seem to fix glitching)



Pins 46-49 are dedicated to debug buttons 1 & 2, progress pin, and error pin



Tree 1-1

Tree 1-2

Tree 2-1

Tree 2-2

Tree 3-1

Tree 3-2